


# ZC100/300 Series




Power Supply

100 – 240 VAC  
50/60 Hz



P1094919-002

## 1 Connect



## 2 Power On



## 3 Install Driver



[www.zebra.com/zc100-info](http://www.zebra.com/zc100-info)  
[www.zebra.com/zc300-info](http://www.zebra.com/zc300-info)



ZEBRA

©2017 ZIH Corp and/or its affiliates. All rights reserved. Zebra and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective holders. Printed in China.



### Load Ribbon

1



2



3



4




### Load Cards

1



2



3



### Manual Card Feed



### Indicators

Power On



Ready



Power Off



Critical Error



Card Error



Ribbon Error



Clean Printer



Clean Printer; Reject Bin Full



[www.zebra.com/zc100-info](http://www.zebra.com/zc100-info)



[www.zebra.com/zc300-info](http://www.zebra.com/zc300-info)