








# Zebra Access Management System Cabinet and Mobile Device Quick Reference Guide

When the device is placed on charge, the Zebra Access Management System (ZAMS) application displays the charging screen with a battery status indicator.

**Table 1** Battery Status Indications


Battery Status Indicator	Description
	Full battery
	Less than half battery
	Low battery
	Critically low battery

1. Only select devices that are fully charged.



2. Once the device is removed from the cradle, the ZAMS application prompts you to enter a PIN code.

- If a valid PIN code is not entered within two minutes, an alarm triggers. Place the device back into the cabinet if you do not want to continue using the device.
- If the PIN is invalid, an **invalid pin** message displays. To try again, press the back arrow on the screen to delete each digit of the PIN code.



3. At the end of shift, return the device to an empty charging cradle in the cabinet from which you obtained it to log off.

Contact your supervisor or help desk for assistance.