

Wall Mount Bracket Kit

Installation Guide

for the SAC5000-8000CR Cradle

Introduction

This guide provides instructions for mounting the KT-102376-01R bracket for use with one SAC5000-8000CR (eight-slot) battery charger.

- ✓ **NOTE** Refer to the CA50 Client/UCA Server Developer Guide (p/n 72E-93914-xx) for detailed product information.

Included Hardware


- One KT-102376-01R Mounting Bracket
- One black .5" Phillips round head, thread cutting screw.

Mounting Instructions




WARNING! Use the screw supplied in this kit to attach the cradle to the mounting bracket only. This screw is not intended for mounting the bracket on a wall.


For safety and stability, it is recommended that you use the appropriate wall mounting hardware for installation. For safe mounting, it is essential to use wall anchors appropriate to the wall type (i.e. plaster, drywall, concrete, etc.). Mount to wood studs whenever possible.



1. Slide the two bracket mounting tabs into the receptacles on the bottom of the cradle as shown. Ensure the screw hole in the bracket flange aligns with the screw hole in the cradle.



2. Screw the .5" Phillips screw (supplied) into the bracket flange and tighten until the cradle is securely attached to the bracket.



3. Use four screws to mount the bracket to a wall. Ensure to use additional wall mounting hardware, as needed, for safe mounting to the wall type.

© 2015 Symbol Technologies, Inc.

Zebra reserves the right to make changes to any product to improve reliability, function, or design. Zebra does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any patent right or patent, covering or relating to any combination, system, apparatus, machine, material, method, or process in which Zebra products might be used. An implied license exists only for equipment, circuits, and subsystems contained in Zebra products.

Zebra and the Zebra head graphic are registered trademarks of ZIH Corp. The Symbol logo is a registered trademark of Symbol Technologies, Inc., a Zebra Technologies company.

Warranty

For the complete Zebra hardware product warranty statement, go to: <http://www.zebra.com/warranty>. Refer to the CA50 Client/UCA Server Developer Guide (p/n 72E-93914-xx) for detailed product information. For the latest guide, visit: <http://www.zebra.com/support>.



Zebra Technologies Corporation
Lincolnshire, IL U.S.A.
<http://www.zebra.com>

Zebra and the Zebra head graphic are registered trademarks of ZIH Corp. The Symbol logo is a registered trademark of Symbol Technologies, Inc., a Zebra Technologies company.

© 2015 Symbol Technologies, Inc.

